
Product Computer Software

10.1 Overview

Your computer hardware and ground electronics are provided with all required software installed; however, this chapter provides instructions should you need to install or upgrade the software.

See the following sections for more information:

- ◆ *"Windows Configuration and Settings" on page 139*
- ◆ *"Changing the System Time" on page 168*
- ◆ *"Setting the Time Zone" on page 168*
- ◆ *"Daylight Saving Time" on page 170*
- ◆ *"Burn a CD" on page 170*
- ◆ *"Enable NTP Server" on page 181*
- ◆ *"Installing Third-Party Software" on page 196*
- ◆ *"Installing or Updating the Product System Software" on page 211*
- ◆ *"Opening the System Console" on page 222*
- ◆ *"Troubleshooting a Linux/Windows or Windows Installation" on page 225*
- ◆ *"Mapping the B Drive" on page 238*
- ◆ *"Verify a Drive Mapping" on page 240*
- ◆ *"12. TeamViewer" on page 247*
- ◆ *"14. DHCP Server Configuration" on page 269*

10.2 Windows Configuration and Settings

This section describes the following Windows settings:

- ◆ *"Windows Automatic Updates" on page 139*
- ◆ *"Windows Password Lock on Idle" on page 142*
- ◆ *"Windows Power Settings" on page 146*
- ◆ *"Anti-Virus Protection Software" on page 153*
- ◆ *"Windows Firewall" on page 158*
- ◆ *"Check for Windows Updates" on page 165*



Windows 7 and Windows 10 are the supported operating systems.

10.2.1 Windows Automatic Updates

Windows Automatic Updates must be disabled to ensure the system functions properly without interruption.

See the following sections for instructions:

- ◆ *"Windows 7" on page 140*

- ◆ "Windows 10" on page 140

10.2.1.1 Windows 7

This section describes how to disable Windows 7 automatic updates.

To disable automatic updates:

→ **Windows 7 computer** → **Desktop**

- 1 Check prerequisites:
 - ✓ None
- 2 Click **Start** → **All Programs** → **Windows Update**.
- 3 In the left pane, click **Change settings**.




Figure 10–1 Windows Automatic Updates

- 4 Click one of the following options:
 - Check for updates but let me choose whether to download and install them
 - Never check for updates
- 5 Click **OK**.

10.2.1.2 Windows 10

This section describes how to disable Windows 10 automatic updates.

To disable automatic updates:

→ **Windows 10 computer** → **Desktop**

- 1 Check prerequisites:
 - ✓ None

- 2 In the **Windows** search box, type `services.msc`.




Figure 10–2 Windows 10, services.msc

- 3 Click **Services**. Click **Yes** at the security prompt.
- 4 The **Services** window opens.




Figure 10–3 Windows 10, Services Windows Update

- 5 Scroll down and then right-click **Windows Update**.

- 6 Click **Properties**. The **Windows Update Properties** window opens.




Figure 10–4 Windows 10, Windows Update Properties

- 7 Select the **Startup Type** of **Disabled**.
- 8 Click **Apply**.
- 9 Click **OK**.
- 10 Close the **Services** window.



NOTE

If you need to install Windows Updates, you must change this setting to Manual. For instructions, see "Enable Windows Automatic Updates" on page 166.

10.2.2 Windows Password Lock on Idle

Requiring a password to recover from an idle condition (sleep or screen saver) must be disabled to ensure the system functions properly without interruption.

See the following sections for instructions:

- ◆ "Windows 7" on page 142
- ◆ "Windows 10" on page 143

10.2.2.1 Windows 7

This section describes how to disable the Windows 7 password lock.

To disable password lock:

→ **Windows 7 computer** → **Desktop**

- 1 Check prerequisites:

- ✓ None
- 2 Click **Start** → **Control Panel**.
- 3 Click **Appearance and Personalization**




Figure 10–5 Windows Change Screen Saver

- 4 Click **Change screen saver**.




Figure 10–6 Windows Screen Saver Login Check Box

- 5 Clear the **On resume, display logon screen** check box.
- 6 Click **OK**.

10.2.2.2 Windows 10

This section describes how to disable the Windows 10 password lock.

To disable password lock:

→ **Windows 10 computer** → **Desktop**

- 1 Check prerequisites:
 - ✓ None
- 2 In the **Windows** search box, type screen.

10. Product Computer Software

Windows Configuration and Settings

- 3 Click **Turn screen saver on or off**. The **Screen Saver Settings** window opens.




Figure 10–7 Windows 10, Screen Saver Settings

- 4 Make the following selections:
 - **Screen saver – None**
 - **On resume, display login screen** check box – **Cleared**
- 5 Click **OK**.
- 6 In the **Windows** search box, type `settings`.

7 Click **Settings**. The **Settings** window opens.




Figure 10–8 Windows 10, Settings




Figure 10–9 Windows 10, Settings, Accounts

- 8 Click **Accounts**. The **Settings** window opens.




Figure 10–10 Windows 10, Settings, Sign-in Options

- 9 Click **Sign-in options**.




Figure 10–11 Windows 10, Settings, Require Sign-in

- 10 In the **Require sign-in** area, select **Never**.
- 11 Close the **Settings** window.

10.2.3 Windows Power Settings

If the Windows server computer goes into an idle state, the drives used in the **File System Manager** could become unavailable. If this happens, there could be errors when attempting to write data to the drive, or open a file from the drive. To prevent this situation, change the **Windows Power Options** settings so that the hard drive does not sleep.

See the following sections for instructions:

- ◆ "Windows 7" on page 146
- ◆ "Windows 10" on page 148

10.2.3.1 Windows 7

This section describes how to change the Windows 7 power options.

To change the Windows Power Options:

→ **Windows 7 computer** → **Desktop**

- 1 Check prerequisites: