
3.3 Setting up the Backhaul

This section provides instructions on how to assemble the backhaul components.

Table 3-13 How to Set Up the Backhaul



Product Guide 57

Setting up the Backhaul

Table 3-13 How to Set Up the Backhaul

6 Attach the mast [M-3] to the base [B-1]. Tighten both knobs [B-2]. 7 Position four stakes equal distances apart at approximately 20 ft (6 m) from the base. Pound them into the ground.